

Step 3.

Attach the lower shoe rack as shown.

You can easily insert them in as all A and B rods are yet to be fully tightened.



Note:

EH3000 in folded up position for easy storage